





Spare Parts List



*EX*Trend / *EXW*Trend


2015-02-17

EX / EXW Trend




Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4510-04		41	9969-31	M8
2	4510-09		42	4520-01	EX
3	9969-16	M6	42	4520-20	EXW
4	9930-02	D6/12	43	4612-01	
5	9961-12	M6x20	44	4611-00	
6	9934-13	Ø1,5x11x32	45	4223-24	Kat 2
7	4513-07		46	9963-03	M10x75
8	4513-02		47	4470-01	
9	4930-69		48	9962-03	M8x16
10	9963-01		M10x25	49	4930-82
11	3210-05	D10x21 M10	50	9987-12	
12	9968-44		51	4930-80	
13	9969-45		52	9929-39	M4x25
14	4110-31		53	9968-78	M4
15	4016-05		54	9991-95	
16	9913-20	M8x10	55	9990-43	
17	4512-13	Left	56	9985-40	810 mm
18	4512-14	Right	57	4223-21	Kat 3
19	4512-05	Big, left	58	4571-04	
20	4512-06	Big, right	59	4412-20	Big
21	4512-08	Small, left	60	4412-21	Small
22	4512-09	Small, right	61	4573-01	
23	4512-12		62	9933-25	Ø2x10
24	4512-11		63	4571-10	
25	4012-11		64	4951-84	
26	4511-06	U44	65	4970-81	
27	4310-07	M10/M8	66	9990-43	
28	9969-32	M8	67	0676-02	
29	9930-32	D8/17			
30	4541-03				
31	4541-04				
32	4572-01				
33	9961-11	M6x12			
34	9969-15	M6			
35	9930-03	D6/18			
36	4571-01	Left Stainless			
37	4571-02	Right Stainless			
38	4571-03				
39	4540-01				
40	9962-04	M8x20			


EX / EXW Trend



Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4750-02	540/750 rpm	42	4652-09	
2	4160-01	Right	43	9950-03	6206-2RS
3	4160-02	Left	44	4652-01	
4	4056-10		45	3260-09	
5	4056-03		46	9990-90	
6	4058-05	Right	47	3263-00	
7	4058-06	Left	48	3260-07	
8	4161-02	Left	49	9965-02	M12x65
9	4161-01	Right	50	9934-03	
10	4158-05		51	9969-60	M12
11	9913-20	M8x10	52	4653-10	
12	4560-01	Ø20xØ30x5	53	9934-02	
13	9929-35	M8x20	54	4653-02	
14	9930-32	D8/17	55	9990-99	14x20x10
15	9969-31	M8	56	9936-29	14x22x4
16	4550-05	Left	57	9934-31	
17	4550-06	Right	61	9930-07	D6/17
18	9933-02	Ø8x40	62	9961-04	M6x16
19	9933-11	Ø5x40	63	9962-03	M8x16
20	4051-05		64	9965-01	M12x35
21	9936-37	35x62x12	65	9930-35	D12/24
22	9950-02	6305-2RS	66	9969-62	M12
23	4155-04	Right thread	67	4650-12	E1 T 2 Left/ 2 Right
24	9933-12	Ø8x45	67	4650-20	E2 T 2 Left/ 2 Right
25	9933-17	Ø5x45	67	4650-28	E6 T 2 Left/ 2 Right
26	3265-02	15 teeth	67	4650-36	E8 T 2 Left/ 2 Right
27	3262-05		68	9936-28	
28	3260-04		69	9937-13	U 14
29	9963-07	M10x25	70	9913-19	M8x10
30	3260-05		71	4690-08	
31	4062-05	Left thread	72	9961-12	M6x20
32	4454-05		73	9930-02	D6/17
33	9937-40	I60	74	9969-16	M6
34	4557-02		75	4655-05	
35	4156-02		76	4653-15	
37	9931-56	8x7x25	77	4690-05	
38	4652-03		78	9934-07	
39	4652-08				
40	4652-10	17/24 teeth			
41	4660-00				



EXWTrend



Pos. No.	Order no.	Notes	Pos. No.	Order no.	Notes
1	4581-03		41	9964-73	M16x45
2	9930-31	D8/24	42	9930-20	D17/30
3	9962-03	M8x16	43	4220-26	
4	3961-30		44	4220-25	
5	9969-31	M8	45	4220-27	
6	9930-32	D8/17	46	4522-30	
7	9962-04	M8x20	47	9942-33	
8	4581-04		48	9913-41	M16x90 kv12.9
9	9961-04	M6x16	49	9968-97	M20
10	9930-02	D6/12	50	4220-29	M20x100
11	9969-15	M6	51	9969-46	M10
12	9930-35	D12/24	52	9963-12	M10x30
13	9969-60	M12	53	9968-98	M30
14	4581-36		54	4220-36	D30/52
15	9934-31		55	9965-05	M12x40
16	4581-30	225/260 mm	56	9969-60	M12
17	9934-32		57	4220-38	D30/52
18	4581-29		58	4220-33	
19	9990-52		59	9937-45	I 72
20	4581-10		60	9950-05	6306-2 RS
21	9934-14		61	4220-30	
22	9990-60	D24	62	4220-37	D20/40
23	9987-04		63	9969-94	M20
24	9990-61	D40	64	4222-43	
25	4581-15		65	9985-33	1010 mm
26	9983-29		66	4584-10	EXW
27	9936-79		66	4952-90	EXW 36 m
28	9982-06		67	4522-40	
29	9990-84		68	4522-42	
30	9936-80		69	9930-35	D12/24
31	9983-09		70	9965-07	M12x70
33	9990-19				
34	4581-25				
35	4581-28				
36	4581-37				



Spare parts list *EX*_{Trend} from machine no. 2094
Spare parts list *EXW*_{Trend} from machine no. 686

Reservedelsliste
Ersatzteilliste
Reservdelslista
Lista de piezas de recambio
Liste de pièce de rechange
Onderdelenslijst
Varaosaluettelo

BOGBALLE A/S
Bogballe · DK-7171 Uldum

Tel.: +45 7589 3266
Fax: +45 7589 3766
E-mail: bogballe@bogballe.com
www.bogballe.com